

13 3/8" / 340mm

CALMA®

Step 1: Do you have the right template?

Step 2: Have you printed the template to the correct scale? To confirm, check the measurements on this template.

Step 3: Cut out the template.

Step 4: Use this template to mark and cut the sink hole in your counter.

Cut-out Template For:
B8521 Vittorio

BACK

FRONT

Drain

13 3/8" / 340mm

SCALE 1:1

(Print on 4 sheets of 8.5"x11" Paper)

Have questions?

Contact us:

877-757-8930

cs@icobath.com

www.icobath.com