




Exhilarating by Design

Volkano Summit Glass Soap Dish Installation Guide

Code: V63513, V63514, V63515



| Parts Included | QTY |
|----------------|-----|
| A - Soap Dish | 1 |
| B - Screw | 2 |
| C - Set Screw | 1 |
| D - Allen Key | 1 |
| E - Bracket | 1 |

| Model # | Description | Finish | Weight (lb) | WxHxD (mm) | WxHxD (Inches) | Metal Type |
|---------|------------------------|----------------|-------------|----------------|-----------------|------------|
| V63513 | Summit Glass Soap Dish | Chrome | 1.012 | 144 x 55 x 115 | 5.6 x 2.2 x 4.5 | Brass |
| V63514 | Summit Glass Soap Dish | Brushed Nickel | 1.012 | 144 x 55 x 115 | 5.6 x 2.2 x 4.5 | Brass |
| V63515 | Summit Glass Soap Dish | Matte Black | 1.012 | 144 x 55 x 115 | 5.6 x 2.2 x 4.5 | Brass |

Warranty: 2 Years

Care & Maintenance: A periodic wash using warm water and a soft cloth will retain the high quality finish of your Volkano product for many years to come. ON NO ACCOUNT should any household bleaches, detergents, abrasive polishes, steel wool or other cleaning agents be used on this item.

