

# Heating Element Reversal Guide

---

1. Turn off the towel warmer and ensure that the power supply is disconnected.
2. Remove towel warmer from wall by loosening the set screws located on each bracket.
3. Turn the towel warmer onto its side so the element is at the top.
4. Remove the heating element using a 27mm wrench.
5. Turn towel warmer on a 45-degree angle so that any air bubble that may be inside will come out.
6. Install new heating element, ensuring none of the liquid inside is lost.
7. Tighten, but not over tighten as this could break the seal.
8. Reinstall the towel warmer on the wall.
9. After heating the towel warmer for 2 hours, loosen the bleed valve located at the top of the towel warmer using a flat head screwdriver. **Use caution** – You should hear air being released from the towel warmer. Retighten bleed valve or sealed plug.

If you have any questions at any point during the process, please call **1-877-757-8930** and a representative can walk you through it!

